

General Information

This parts catalogue covers all service parts for SUZUKI SX4
RW415, RW415-3, RW415-4, RW416, RW416-2, RW416-3, RW416-4, RW416-5,
RW416-6, RW420, RW420-2, RW420-3, RW420-4, RW420-5 and RW420-6.

1. Location of the model Identification Plate.

ID. Plate

2. Information in the Identification Plate.

For the E10,E24,E30,E31,E35,E37,
E38,E43,E48,E70,E85,E96
Specifications

SUZUKI MOTOR CORPORATION JAPAN	
TYPE	①
CHASSIS NO.	②
ENGINE	③
○ COLOR	④
	⑤

For the E2,E5,E6,E22,E54,E90
Specifications

SUZUKI MOTOR CORPORATION	
No.	
V.I.N. No.	②
	Kg
	Kg
1-	Kg
2-	Kg
TYPE	①
ENGINE	③
COLOR	④
	⑤

① Type : type of vehicle

② Chassis No.: starting from

TYPE 1

- RW415:E35
JSAGYB11S00100001~(5DR)
- RW416:E2,E22,E30,E38
JSAGYC21S00100001~(4DR)
JSAGYA21S00100001~(5DR)
- RW416:E10,E43,E85
JS2YC21S 85100001~(4DR:2008 MODEL)
JS2YC21S 95100001~(4DR:2009 MODEL)
JS2YA21S 75100001~(5DR:2007 MODEL)
JS2YA21S 85100001~(5DR:2008 MODEL)
JS2YA21S 95100001~(5DR:2009 MODEL)
- RW416:E54
JSAGYC21S80100001~(4DR:2008 MODEL)
JSAGYC21S90100001~(4DR:2009 MODEL)
- RW420:E10
JS2YC41S 85100001~(4DR:2008 MODEL)
JS2YC41S 95100001~(4DR:2009 MODEL)
- RW420:E24
JSAGYC41S00100001~(4DR)
JSAGYA41S00100001~(5DR:2WD)
JSAGYB41S00100001~(5DR:4WD)
- RW420:E35
JSAGYB41S00100001~(5DR)
- RW420:E43
JS2YC41S 85100001~(4DR)
JS2YA41S 75100001~(5DR)

TYPE 2

- RW416:E38
JSAGYA21S00150001~(5DR)
- RW420:E6
JSAGYA41S00110001~(5DR)
- RW420:E24
JSAGYA41S00110001~(5DR:2WD)
JSAGYB41S00110001~(5DR:4WD)
- RW420:E43
JS2YA41S 85100001~(5DR:2008 MODEL)
JS2YA41S 95100001~(5DR:2009 MODEL)

TYPE 3

- RW415:E35
JSAGYC11S00200001～(4DR)
JSAGYB11S00200001～(5DR)
- RW416:E2,E22,E30,E38
JSAGYC21S00200001～(4DR)
JSAGYC21S00250001～(4DR:E2,E22:2009-1～)
JSAGYA21S00200001～(5DR)
JSAGYA21S00250001～(5DR:E2,E22:2009-1～)
- RW416:E10,E31,E43,E85
JS2YC21S 96200001～(4DR)
JS2YC21S A6200001～(4DR:E10,E31:2009-2～)
JS2YA21S 96200001～(5DR)
- RW416:E54
JSAGYC21S90200001～(4DR)
JSAGYC21S90250001～(4DR:2009-1～)
JSAGYA21S90200001～(5DR)
JSAGYA21S90250001～(5DR:2009-1～)
- RW420:E6
JSAGYA41S00200001～(5DR)
- RW420:E10
JS2YC41S 96200001～(4DR)
JS2YC41S A6200001～(4DR:2009-2～)
- RW420:E24
JSAGYC41S00200001～(4DR)
JSAGYA41S00200001～(5DR:2WD)
JSAGYB41S00200001～(5DR:4WD)
- RW420:E35
JSAGYB41S00200001～(5DR)
- RW420:E37
JSAGYA41SA6200001～(5DR:2WD)
JSAGYB41SA6200001～(5DR:4WD)
- RW420:E43
JS2YC41S 96200001～(4DR)
JS2YA41S 96200001～(5DR)

TYPE 4

- RW415:E35
YB11S-300001～
YC11S-300001～
- RW416:E2,E22,E30,E38
JSAGYC21S00300001～(4DR)
JSAGYC21S00310001～(4DR:2009-5～)
JSAGYC21S00320001～(4DR:2009-11～)
JSAGYC21S00330001～(4DR:2009-12～)
JSAGYC21S00340001～(4DR:2010-4～)
JSAGYC21S00350001～(4DR:2010-8～)
JSAGYA21S00300001～(5DR)
JSAGYA21S00310001～(5DR:2009-5～)
JSAGYA21S00320001～(5DR:2009-11～)
JSAGYA21S00330001～(5DR:2009-12～)
JSAGYA21S00340001～(5DR:2010-4～)
JSAGYA21S00350001～(5DR:2010-8～)
- RW416:E5
JSAGYC21S00310001～(4DR)
JSAGYC21S00320001～(4DR:2009-11～)
JSAGYC21S00330001～(4DR:2009-12～)
JSAGYC21S00340001～(4DR:2010-4～)
JSAGYC21S00350001～(4DR:2010-8～)
JSAGYA21S00310001～(5DR:2WD)
JSAGYA21S00320001～(5DR:2WD:2009-11～)
JSAGYA21S00330001～(5DR:2WD:2009-12～)
JSAGYA21S00340001～(5DR:2WD:2010-4～)
JSAGYA21S00350001～(5DR:2WD:2010-8～)
JSAGYB21S00310001～(5DR:4WD)
JSAGYB21S00320001～(5DR:4WD:2009-11～)
JSAGYB21S00330001～(5DR:4WD:2009-12～)
JSAGYB21S00340001～(5DR:4WD:2010-4～)
JSAGYB21S00350001～(5DR:4WD:2010-8～)
- RW416:E10,E43,E85
JS2YC21S A6300001～(4DR)
JS2YA21S A6300001～(5DR:2WD)
JS2YB21S A6300001～(5DR:4WD)
- RW416:E70
JSAGYB21S00300001～(5DR)
JSAGYB21S00310001～(5DR:2009-5～)
JSAGYB21S00320001～(5DR:2009-11～)
JSAGYB21S00330001～(5DR:2009-12～)
JSAGYB21S00340001～(5DR:2010-4～)
JSAGYB21S00350001～(5DR:2010-8～)

- RW416:E90
 - JSAGYC21S00300001～(4DR)
 - JSAGYC21S00310001～(4DR:2009-5～)
 - JSAGYC21S00320001～(4DR:2009-11～)
 - JSAGYC21S00330001～(4DR:2009-12～)
 - JSAGYC21S00340001～(4DR:2010-4～)
 - JSAGYC21S00350001～(4DR:2010-8～)
 - JSAGYA21S00300001～(5DR:2WD)
 - JSAGYA21S00310001～(5DR:2WD:2009-5～)
 - JSAGYA21S00320001～(5DR:2WD:2009-11～)
 - JSAGYA21S00330001～(5DR:2WD:2009-12～)
 - JSAGYA21S00340001～(5DR:2WD:2010-4～)
 - JSAGYA21S00350001～(5DR:2WD:2010-8～)
 - JSAGYB21S00300001～(5DR:4WD)
 - JSAGYB21S00310001～(5DR:4WD:2009-5～)
 - JSAGYB21S00320001～(5DR:4WD:2009-11～)
 - JSAGYB21S00330001～(5DR:4WD:2009-12～)
 - JSAGYB21S00340001～(5DR:4WD:2010-4～)
 - JSAGYB21S00350001～(5DR:4WD:2010-8～)

- RW420:E6
 - JSAGYC51S00300001～(4DR)
 - JSAGYA51S00300001～(5DR:2WD)
 - JSAGYB51S00300001～(5DR:4WD)

- RW420:E24
 - JSAGYC51S00300001～(4DR)
 - JSAGYA51S00300001～(5DR:2WD)
 - JSAGYB51S00300001～(5DR:4WD)

- RW420:E37
 - JSAGYA41SA6300001～(2WD)
 - JSAGYA41SB6300001～(2WD:2010-4～)
 - JSAGYA41SC6300001～(2WD:2011-4～)
 - JSAGYB41SA6300001～(4WD)
 - JSAGYB41SB6300001～(4WD:2010-4～)
 - JSAGYB41SC6300001～(4WD:2011-4～)

- RW420:E43
 - JS2YC51S A6300001～(4DR)
 - JS2YC51S B6300001～(4DR:2010-5～)
 - JS2YC51S C6300001～(4DR:2011-6～)
 - JS2YA51S A6300001～(5DR:2WD)
 - JS2YA51S B6300001～(5DR:2WD:2010-5～)
 - JS2YA51S C6300001～(5DR:2WD:2011-6～)
 - JS2YB51S A6300001～(5DR:4WD)
 - JS2YB51S B6300001～(5DR:4WD:2010-5～)
 - JS2YB51S C6300001～(5DR:4WD:2011-6～)

TYPE 5

- RW416:E10
 - JS2YC21S B6300001～(4DR)
 - JS2YC21S C6300001～(4DR:2011-2～)
 - JS2YC21S D6300001～(4DR:2012-1～)
 - JS2YA21S B6300001～(5DR:2WD)
 - JS2YA21S C6300001～(5DR:2WD:2011-2～)
 - JS2YA21S D6300001～(5DR:2WD:2012-1～)
 - JS2YB21S B6300001～(5DR:4WD)
 - JS2YB21S C6300001～(5DR:4WD:2011-2～)
 - JS2YB21S D6300001～(5DR:4WD:2012-1～)
- RW420:E6
 - JSAGYB51S00300001～(5DR)
 - JSAGYB51S00310001～(5DR:2011-11～)
- RW416:E22
 - JSAGYC21S00350001～(4DR)
 - JSAGYC21S00360001～(4DR:2011-11～)
 - JSAGYA21S00350001～(5DR)
 - JSAGYA21S00360001～(5DR:2011-11～)
- RW420:E24
 - JSAGYC51S00300001～(4DR)
 - JSAGYC51S00310001～(4DR:2011-11～)
 - JSAGYA51S00300001～(5DR:2WD)
 - JSAGYA51S00310001～(5DR:2WD:2011-11～)
 - JSAGYB51S00300001～(5DR:4WD)
 - JSAGYB51S00310001～(5DR:4WD:2011-11～)
- RW416:E48
 - JS2YB21S D6300001～(5DR:4WD)
- RW416:E90
 - JSAGYC21S00360001～(4DR)
 - JSAGYA21S00360001～(5DR:2WD)
 - JSAGYB21S00360001～(5DR:4WD)

TYPE 6

- RW416:E5,E22
 - JSAGYC21S00400001～(4DR)
 - JSAGYA21S00400001～(5DR:2WD)
 - JSAGYB21S00400001～(5DR:4WD)
- RW416:E10,E85,E96
 - JS2YC21S D6400001～(4DR)
 - JS2YC21S E6100001～(4DR:2013-1～)
 - JS2YA21S D6400001～(5DR:2WD)
 - JS2YA21S E6100001～(5DR:2WD:2013-1～)
 - JS2YB21S D6400001～(5DR:4WD)
 - JS2YB21S E6100001～(5DR:4WD:2013-1～)

- RW416:E30
JSAGYC21S00400001～(4DR)
JSAGYA21S00400001～(5DR)

- RW416:E38
JSAGYA21S00400001～(5DR)

- RW416:E43
JS2YC2A1 D6100001～(4DR)
JS2YA2A1 E6100001～(5DR)
JS2YB5A1 E6100001～(5DR:4WD)

- RW416:E48
JS2YB21S D6400001～(5DR)
JS2YB21S E6100001～(5DR:2013-2～)

- RW420:E6,E24
JSAGYC51S00400001～(4DR)
JSAGYA51S00400001～(5DR:2WD)
JSAGYB51S00400001～(5DR:4WD)

- RW420:E37
JSAGYB41SD6400001～(5DR)

- RW420:E43
JS2YC5A1 D6100001～(4DR)
JS2YA5A1 D6100001～(5DR:2WD)
JS2YB5A1 D6100001～(5DR:4WD)
JS2YB5A1 E6100001～(5DR:4WD:2013-1～)

③ Engine : type of engine

④ Color : color code of the vehicle

⑤ Model code : nine-digit code is provided

Model code is provided for easier and exact distinction of the model among various models available due to combination of different grade, intended market etc.

The composition of model code and the meaning of letter (alphabet) or numeral at each digit are as follows.

The model code is composed of 9 characters. Taking the code "H3N6ABA10" for instance,

- 1). The First character indicates body type by letter;
"H" means Hatch back type.
- 2). The 2nd character indicates model series by letter;
- 3). The 3rd character indicates door type by letter;
- 4). The 4th and 5th characters indicate the combination of engine and transmission in this model series;
"6A" means the combination of a 4 cycle, 4 cylinder, 1600cc engine and floor shift type 5 speed transmission.
- 5). The 6th character indicates air bag;
"B" means 2AB.
- 6). The 7th character is provided for model change indication in combination with type of model series;
- 7). The 8th and 9th characters indicate the specification code;
"10" means spec. code E10.

As can be seen from 1) through 7) above, model code H3N6A1A10 means; Hatch back type 5 seater, 4 cycle, 4 cylinder, 1600cc engine, 5-speed manual transmission, 2AB, with E10 specs.

A reference table between model code and indications in the remarks column of the parts catalogue is shown below.

Character	*Model Code	Description	Indication in remarks column of catalogue
1st	S	Sedan type	4DR
	H	Hatch back type	5DR
2nd	3	Model series	RW SERIES
3rd	L	Door type	4DR
	N		5DR
4th 5th	6A	Engine and Transmission	RW416:2WD:MT:N/VVT
	6B		RW416:2WD:AT:N/VVT
	6E		RW416:2WD:MT:W/VVT
	6F		RW416:2WD:AT:W/VVT
	6G		RW416:4WD:MT:W/VVT
	6H		RW416:4WD:AT:W/VVT
	80		RW420:4WD:MT
	83		RW420:2WD:MT
	84		RW420:2WD:AT
	85		RW420:4WD:AT
	8L		RW415:2WD:AT
	8N		RW415:4WD:AT
	B1		RW420:2WD:6MT
	B2		RW420:4WD:6MT
	B6		RW420:2WD:CVT
	B7		RW420:4WD:CVT

Market Code : E2

6th	8,H	Grade etc	W/6AB
	M		W/6AB,ROOF RAIL
	7,L		W/6AB,KEYLESS START,LEATHER STEERING, AUTO AIR CONDITIONER
	N		W/6AB,KEYLESS START,LEATHER STEERING, AUTO AIR CONDITIONER,ROOF RAIL
	Q		W/6AB,KEYLESS START,AUTO AIR CONDITIONER

Market Code : E5,E10,E31

6th	B	Grade etc	W/2AB
			W/2AB (4DR)
	C		W/2AB,SPLASH GUARD, UNDER SPOILER,ROOF RAIL (5DR)
	D		W/2AB,UNDER SPOILER
	E		W/2AB,UNDER SPOILER,LEATHER STEERING

Market Code : E6

6th	J	Grade etc	W/6AB
	4		W/6AB,EPS

Market Code : E22,E90

6th	9,B	Grade etc	W/2AB
	6		W/2AB,ROOF RAIL
	8,H		W/6AB
	M		W/6AB,ROOF RAIL
	1		W/6AB,ESP
	2		W/6AB,ESP,LEATHER STEERING
	3		W/6AB,KEYLESS START,ESP, AUTO AIR CONDITIONER,ROOF RAIL
	4		W/6AB,KEYLESS START,ESP,LEATHER STEERING,AUTO AIR CONDITIONER,ROOF RAIL
	7,L		W/6AB,KEYLESS START,LEATHER STEERING, AUTO AIR CONDITIONER
	N		W/6AB,KEYLESS START,LEATHER STEERING, AUTO AIR CONDITIONER,ROOF RAIL

Market Code : E24

6th	1	Grade etc	W/6AB,ESP
	2		W/6AB,ESP,LEATHER STEERING
	3		W/6AB,KEYLESS START,ESP, AUTO AIR CONDITIONER,ROOF RAIL
	4		W/6AB,KEYLESS START,ESP,LEATHER STEERING,AUTO AIR CONDITIONER,ROOF RAIL
	9		W/2AB
	H		W/6AB
	J		W/6AB,KEYLESS START,LEATHER STEERING, AUTO AIR CONDITIONER,CRUISE CONTROL

Market Code : E30,E85

6th	C	Grade etc	W/2AB
	D		W/2AB,AUTO AIR CONDITIONER

Market Code : E35

6th	1,K	Grade etc	W/6AB,KEYLESS START,LEATHER STEERING, AUTO AIR CONDITIONER
	3		W/6AB,KEYLESS START,LEATHER STEERING, AUTO AIR CONDITIONER,ESP
	C		W/6AB,KEYLESS START, AUTO AIR CONDITIONER

Market Code : E37

6th	9	Grade etc	W/2AB, LEATHER STEERING
-----	---	-----------	-------------------------

Market Code : E38,E43

6th	C	Grade etc	W/2AB
	H		W/6AB

Market Code : E48

6th	C	Grade etc	W/2AB
-----	---	-----------	-------

Market Code : E54,E70

6th	8,H	Grade etc	W/6AB
	2		W/6AB,ESP
	7,L		W/6AB,KEYLESS START,LEATHER STEERING, AUTO AIR CONDITIONER
	4		W/6AB,KEYLESS START,LEATHER STEERING, AUTO AIR CONDITIONER,ESP

Market Code : E96

6th	B	Grade etc	W/2AB
	C		W/2AB (4DR)
			W/2AB,W/ROOF RAIL (5DR)

7th	A	Type of model	TYPE 1
	B		TYPE 2
	D,E		TYPE 3,4
	F		TYPE 5
	H		TYPE 6
8th 9th	2... ...90	Market Code	E2,E5,E6,E10,E22,E24,E30,E31,E35,E37 E38,E43,E48,E54,E70,E85,E90

* Model Code elements listed in the model code column show all the code element existing at the time of compilation of this catalogue.

New code element will be provided in future when different model of vehicles are put into production.

3. Engine Serial Number

Engine Serial Number for RW415,RW416 and RW420 model is provided in the location illustrated below, starting from M15A-1000001(RW415),
M16A-1000001(RW416),
J20A-100001(RW420),
J20B-100001(RW420).

Location of punched engine serial number.

4. Dimensions

Dimensions of the parts in this catalogue are indicated in unit millimeters.

5. Abbreviations

Abbreviations used in this catalogue are as follows:

A	: Ampere	NGK	: NGK SPARK PLUG
ABS	: Antilock Brake System	NO.	: Number
AH	: Ampere Hour	NT	: Number of teeth
AM	: Amplitude Modulation		
AR	: As Required	OD	: Outside Diameter
ASSY	: Assembly	OHTSU	: OHTSU TIRE & RUBBER
AT	: Automatic Transmission	OPNG	: Opening
		OPT	: Optional
BRKT	: Bracket	OS	: Over Size
BS	: BRIDGESTONE TIRE		
		PCV	: Positive Crankcase ventilation
COLPS	: Collapsible		
COMB	: Combination		
CTR	: Center	QTR	: Quarter
D	: Diameter of Material	R	: Right hand side
DF	: Defogger	REV	: Reverse
DIFF	: Differential	RH	: Right hand side
DMR	: Dimmer	RHD	: Right Hand Drive
DR	: Door	RR	: Rear
DRL	: Day-Time Running Light	RSV	: Reserve
E.L.R	: Emergency Lock Retractor	SPNSN	: Suspension
E.NO.	: Engine Number	STD	: Standard
EXC	: Except	SYNC	: Synchronizer
ESP	: Electronic Stability Program		
		T	: Thickness
FL	: Floor	TACH	: Tachometer
FLEX	: Flexible	TEMP	: Temperature
FLTR	: Filter		
FM	: Frequency Modulation	US	: Under Size
FR	: Front		
		VIN	: Vehicle Identification Number
GAS	: Gasoline	W	: Wide
		W/	: With
HR	: Hour		
HSG	: Housing	&	: and
ID	: Inside Diameter or Identification	1ST	: First
INR	: Inner	2AB	: Front Dual Air Bag
		2ND	: Second
L	: Length or Left hand side	2WD	: 2 Wheel Drive
LCD	: Liquid Crystal Display	3RD	: Third
LH	: Left hand side	4DR	: 4 door
LHD	: Left hand Drive	4TH	: Fourth
		4WD	: 4 Wheel Drive
MT	: Manual Transmission	5DR	: 5 door
		5TH	: Fifth
N/	: Non	6AB	: 2AB and side Air Bag and side curtain Air Bag

~JSAGYA21S00100001 : Up to V.I.N.JSAGYA21S00100001
 ~M16A-1000001 : Up to Engine NO.M16A-1000001
 JSAGYA21S00100001 ~ : from V.I.N JSAGYA21S00100001
 M16A-1000001 ~ : from Engine NO.M16A-1000001

12 x 34 x 10 Figures in the description column show
 | | | the millimeter dimensions of parts.
 ID OD T(or W,L)

→12345-63J00 (Parts No.) : Indicates that the part no. was changed to
 12345-63J00 and the new parts are interchangeable with former ones, but
 the former ones are not interchangeable with the new ones.

←12345-63J00 (Parts No.) : Indicates that the former and new parts
 are interchangeable with each other and both are usable.

6. Inner parts of an assembly

Part numbers that have a period (.) mark in front of the description on a text
 page are separately-available parts of the assembly.

7. Parts Change Notice

A parts bulletin will be sent to you on all occasions when changes in parts
 occur, including interchangeable informations between new parts
 and old ones.

8. Notes

- 8-1. There are sometimes differences between spare parts and those
 originally used in of production models due to administrative reasons
 and common use with other models.
- 8-2. Rubber hoses and vinyl tubes should be cut to size in accordance with
 information detailed in the parts catalogue.
- 8-3. Note that the drawing on the illustration pages are for ready reference
 of spare parts numbers and are not to be used as an assembly manual.
 When assembling, please refer to the appropriate
 "SUZUKI SERVICE MANUAL".

9. Specification code

This catalogue contains the parts for the models designed for the following
 markets:

Spec. Code : E2,E5,E6,E10,E22,E24,E30,E31,E35,E37,E38,E43,E48,E54,
 (Market code) E70,E85,E90 and E96.